



REDRAGON DITIX Mechanical Gaming Keyboard



Please scan here to download user manual

RGB Mechanical One Handed Gaming Keypad Operating Instructions

US UK

Dear user

Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within warranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot stick) and spare parts replacement are not included in our warranty.

OS support

Windows XP/Vista/Win7/Win8/Win10

Button and slot instruction



1

How to connect the keyboard to PC

1. Computer USB port interfaces with the keyboard without needing to install drivers or software.
2. Detachable cable Type C to USB to connect keyboard to PC.

Function Introduction

There is a mode switch button on bottom of keyboard, select PC mode or game mode, PC mode for PC game keyboard function, game mode for PS3/PS4/Switch/Xbox one function.

In PC mode

1. There are 5 backlighting effects by press FN+Space: Go with the stream, The trial of Light, Ripple Graff, Flowers blooming, Pass without Trace.
 2. FN+ESC: Press and hold for 3 seconds, back to factory setting.
 3. 4 Pre-set backlights modes: M1 (Default as F9) Go with the stream M2(Default as F10) The trial of Lights M3 (Default as F11) The Ripple Graff M4(Default as F12) Pass without trace
 4. 7 Macro keys for recording: G1,G2,G3,G4,G5 (G1-G5 default as F1-F5),-T
 5. M key is Map key in game.
 6. How to recording by macro keys?
 - Step 1: Press REC key, get ready for recording.
 - Step 2: select the light modes by press M1-M4.
 - Step 3: Select the macro key from 7 buttons(G1-G5,-T).
 - Step 4: Input the keys to be recorded (7 Macro keys G1 ,G2, G3,G4,G5,-T are not available for recording).
 7. Press REC to save the recording.
- Noted: Every macro recording need to be coordinate with a light mode while it is recording and play.

2

In Game mode

How to start the mapping?
Put the mode switch button on game mode, connect the original gamepad to the keyboard for mapping the gamepad key function to keyboard and mouse.

How to setting?

1. Plug the original gamepad to keyboard.
 2. Press ESC+SPACE to start the keyboard/mouse function.
 3. Press and hold the desired key of gamepad.
 4. Press the keyboard/mouse desired key.
 5. Release the gamepad home key.
 6. Then the desired key of gamepad function mapping to desired key of keyboard/mouse.
 7. Press ESC+SPACE to quit the setting.
- Remark: To mapping the joystick function to keyboard, it must be push the joystick to the end at Left/right/up/down, the keyboard is only support 4 direction function (left/right/up/down), not available for 8 direction setting.

Some keyboard setting

Mouse axis direction switching: ESC+CAP+A/S/D/F/G
Mouse Y axis direction switching: ESC+R
Start to setting or Quit setting: ESC+SPACE
Default page: ESC+CTRL+Q

3

Mouse speed adjustment(Total 5 level, default as level 3): ESC+CAP+A/S/D/F/G
Page area adjustment: ESC+TAB+Q/W/E/R/T/Y/U/I
Update in Windows: ESC+B+ALT+SPACE(Press and hold for 3 seconds)

Default mice Key mapping

Mouse Button	Replace Button			
	Nintendo Switch	Xbox one	PS 4	PS 3
Right Button	ZL	LT	L2	L2
Left Button	ZR	RT	R2	R2
Middle Button	R3	R3	R3	R3
Mouse Move UP	Right Joystick UP	Right Joystick UP	Right Joystick UP	Right Joystick UP
Mouse Move LEFT	Right Joystick LEFT	Right Joystick LEFT	Right Joystick LEFT	Right Joystick LEFT
Mouse Move DOWN	Right Joystick DOWN	Right Joystick DOWN	Right Joystick DOWN	Right Joystick DOWN
Mouse Move RIGHT	Right Joystick RIGHT	Right Joystick RIGHT	Right Joystick RIGHT	Right Joystick RIGHT

4

Default keyboard Key Mapping:

Keyboard Button	Replace Button			
	Nintendo Switch	Xbox One	PS 4	PS 3
Button Q	L	LB	L1	L1
Button E	R	RB	R1	R1
Button F1	Dpad UP	Dpad UP	Dpad UP	Dpad UP
Button 1	Dpad LEFT	Dpad LEFT	Dpad LEFT	Dpad LEFT
Button 2	Dpad DOWN	Dpad DOWN	Dpad DOWN	Dpad DOWN
Button 3	Dpad RIGHT	Dpad RIGHT	Dpad RIGHT	Dpad RIGHT
Button R	Y	Y	△	△
Button F	X	X	□	□
Button C	B	B	○	○
Button SPACE	A	A	×	×
Button W (UP)	Left Joystick UP	Left Joystick UP	Left Joystick UP	Left Joystick UP

5

Button A (LEFT)	Left Joystick LEFT	Left Joystick LEFT	Left Joystick LEFT	Left Joystick LEFT
Button S (DOWN)	Left Joystick DOWN	Left Joystick DOWN	Left Joystick DOWN	Left Joystick DOWN
Button D (RIGHT)	Left Joystick RIGHT	Left Joystick RIGHT	Left Joystick RIGHT	Left Joystick RIGHT
Button SHIFT (left side)	L3	L3	L3	L3
Button Tab	-	View	Option	SELECT
Button ESC	Home	/	P5	P5
Button ~	Capture	/	Share	/
Button Caps Lock	+	Menu	/	/

FAQ

1. If the keyboard doesn't respond, please check if the keyboard's USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboard's USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.



6

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

7

RU

Поддержка операционных систем

Windows XP/ Vista/ Win 7/ Win 8/ Win 10

Описание клавиш и разъемов



1

Как подключить клавиатуру к компьютеру

1. Подключение к компьютеру через порт USB без необходимости установки драйверов или программного обеспечения.
2. Отсоединяемая кабель Type C/USB для подключения клавиатуры к ПК.

Описание функций

В нижней части клавиатуры находится кнопка переключения режимов для выбора режима ПК или игрового режима. Режим ПК предназначен для игр на ПК, игровой режим - для устройств PS3/PS4/Switch/Xbox One.

В режиме ПК

1. Нажав FN+Space, можно выбрать один из пяти эффектов подсветки: Поток, Проба света, Рябь, Цветущие цветы, Угасание.
 2. FN+ESC: Нажмите и удерживайте в течение 3 секунд, чтобы выполнить сброс к заводским настройкам.
 3. 4 стандартных режима подсветки:
 - M1 (Клавиша по умолчанию F9) Поток
 - M2 (Клавиша по умолчанию F10) Проба света
 - M3 (Клавиша по умолчанию F11) Рябь
 - M4 (Клавиша по умолчанию F12) Угасание
 4. 7 клавиш для записи макросов: G1, G2, G3, G4, G5 (G1 - G5 по умолчанию как F1 - F5), -, T
 5. Клавиша M - это клавиша Map в игре.
 6. Как выполнять запись с помощью клавиш макросов?
 - Шаг 1: Нажмите клавишу REC и приготовьтесь для начала записи.
 - Шаг 2: выберите режим подсветки, нажав одну из клавиш M1-M4.
 - Шаг 3: Выберите одну из 7 клавиш макросов (G1-G5,-T).
 - Шаг 4: Нажмите клавиши, которые будете записывать (7 клавиш макросов G1, G2, G3, G4, G5,-T, недоступны для записи).
 - Шаг 5: Нажмите клавишу Rec, чтобы сохранить запись.
- ПРИМЕЧАНИЕ: Каждая запись макроса должна быть согласована с режимом подсветки во время записи и воспроизведения.
Например: Записать 123 на G1 при режиме подсветки M1: REC → M1 → G1 → 123 → REC
7. Как воспроизвести макрос? Например: M1 → G1
8. Как удалить макрос? Нажмите FN+ESC для удаления всех макросов.

2

В игровом режиме

Как начать сопоставление клавиш?

3

Переведите кнопку переключения режима в режим игры, подключите игровую панель к клавиатуре, чтобы связать функцию клавиш геймпада с клавиатурой и мышью.

Как выполнить настройку?

1. Подключите геймпад к клавиатуре.
 2. Нажмите ESC+SPACE (Пробел), чтобы запустить функцию клавиатуры/мыши.
 3. Нажмите и удерживайте нужную клавишу геймпада.
 4. Нажмите нужную клавишу клавиатуры/мыши.
 5. Отпустите клавишу геймпада.
 6. В результате этих действий нужная клавиша функции геймпада будет сопоставлена с нужной клавишей клавиатуры/мыши.
 7. Нажмите ESC+SPACE, чтобы выйти из режима настройки.
- Замечание: Для сопоставления функции джойстика с клавиатурой необходимо переместить джойстик до конца влево/вправо/вверх/вниз, клавиатура поддерживает только функцию 4 направлений (влево/вправо/вверх/вниз) и недоступна для настройки 8 направлений (sinistra/destra/su/giù), non disponibile per l'impostazione 8 direzioni.

Некоторые настройки клавиатуры

Переключение направления оси мыши: ESC+CAP+A/S/D/F/G
Переключение направления оси Y мыши: ESC+R
Начать настройку или выйти из режима настроек: ESC+SPACE
Начальная страница: ESC+CTRL+Q
Регулировка скорости мыши (всего 5 уровней, по умолчанию уровень 3): ESC+CAP+A/S/D/F/G
Настройка области страницы: ESC+TAB+Q/W/E/R/T/Y/U/I.
Возврат к заводским настройкам: ESC+CTRL+ALT(нажмите и удерживайте в течение 3 секунд)
Обновить в Windows: ESC+B+ALT+SPACE (нажмите и удерживайте в течение 3 секунд)
Aggiornamento in Windows: ESC+B+ALT+BARRA SPAZIATRICE (Premere e tenere premuto per 3 secondi)

3

Сопоставление клавиш мыши по умолчанию

Кнопка мыши	Заменяющая кнопка			
	Nintendo Switch	Xbox one	PS 4	PS 3
Правая кнопка	ZL	LT	L2	L2
Левая кнопка	ZR	RT	R2	R2
Средняя кнопка	R3	R3	R3	R3
Движение мыши ВВЕРХ	Правый джойстик ВВЕРХ	Правый джойстик ВВЕРХ	Правый джойстик ВВЕРХ	Правый джойстик ВВЕРХ
Движение мыши ВЛЕВО	Правый джойстик ВЛЕВО	Правый джойстик ВЛЕВО	Правый джойстик ВЛЕВО	Правый джойстик ВЛЕВО
Движение мыши ВНИЗ	Правый джойстик ВНИЗ	Правый джойстик ВНИЗ	Правый джойстик ВНИЗ	Правый джойстик ВНИЗ
Движение мыши ВПРАВО	Правый джойстик ВПРАВО	Правый джойстик ВПРАВО	Правый джойстик ВПРАВО	Правый джойстик ВПРАВО

4

Сопоставление клавиш клавиатуры по умолчанию:

Кнопка клавиатуры	Заменяющая кнопка			
	Nintendo Switch	Xbox One	PS 4	PS 3
Кнопка Q	L	LB	L1	L1
Кнопка E	R	RB	R1	R1
Кнопка F1	Крестовина ВВЕРХ	Крестовина ВВЕРХ	Крестовина ВВЕРХ	Крестовина ВВЕРХ
Кнопка 1	Крестовина ВЛЕВО	Крестовина ВЛЕВО	Крестовина ВЛЕВО	Крестовина ВЛЕВО
Кнопка 2	Крестовина ВНИЗ	Крестовина ВНИЗ	Крестовина ВНИЗ	Крестовина ВНИЗ
Кнопка 3	Крестовина ВПРАВО	Крестовина ВПРАВО	Крестовина ВПРАВО	Крестовина ВПРАВО
Кнопка R	Y	Y	△	△
Кнопка F	X	X	□	□
Кнопка C	B	B	○	○
Кнопка ПРОБЕЛ	A	A	×	×
Кнопка W (ВВЕРХ)	Левый джойстик ВВЕРХ	Левый джойстик ВВЕРХ	Левый джойстик ВВЕРХ	Левый джойстик ВВЕРХ

5

Кнопка A (ВЛЕВО)	Левый джойстик ВЛЕВО	Левый джойстик ВЛЕВО	Левый джойстик ВЛЕВО	Левый джойстик ВЛЕВО
Кнопка S (ВНИЗ)	Левый джойстик ВНИЗ	Левый джойстик ВНИЗ	Левый джойстик ВНИЗ	Левый джойстик ВНИЗ
Кнопка D (ВПРАВО)	Левый джойстик ВПРАВО	Левый джойстик ВПРАВО	Левый джойстик ВПРАВО	Левый джойстик ВПРАВО
Кнопка SHIFT (слева)	L3	L3	L3	L3
Кнопка Tab	-	Вид	Option (Опция)	SELECT (Выбрать)
Кнопка ESC	Домой	/	P5	P5
Кнопка ~	Capture (Фотосъемка)	/	Share (Поделиться)	/
Кнопка Caps Lock	+	Меню	/	/

Часто задаваемые вопросы

1. Если клавиатура не отвечает, убедитесь, что ее USB-разъем надежно вставлен в соответствующий USB-порт компьютера, или попробуйте вставить USB-разъем в другой порт компьютера.
2. При пролитии жидкости на клавиатуру, немедленно отсоедините ее USB-разъем от компьютера. Сотрите жидкость и, прежде чем использовать вновь, поместите клавиатуру в теплое место, например, под лампу, чтобы она просохла естественным образом.



6

型号	红龙K601-RGB/8478	备注：尺寸：100x100mm (风琴折页)
名称	说明书	材质：80g书写纸
日期	2021-11-13(修改)	印刷：单黑色双面印刷
页码	1 OF 1	文件编号
绘图	雷国建 审核	核准
		版本 A.0