



REDRAGON

SHARK

Wireless Gaming Mouse

Wireless Gaming Mouse Operating Instructions


Dear user

Thank you for choosing REDRAGON brand. To protect your rights and for better customer service, we ask you note our warranty rules.

1. Within 18 months from purchase date, repair guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot stick) and spare parts replacement, are not included in our warranty.
3. Please fill out the warranty card. Warranty card is valid with the stamp of the retailer.
4. This warranty card will not be reissued if lost. Please keep it in a safe place.

S.O. support

Windows XP/Vista/Win7/Win8



Button functions

1. Left mouse button (Defaulted as click, can't be setting)
2. Right mouse button (Defaulted as click)
3. Scroll wheel button(Middle mouse button)
4. Side button 1 (Defaulted to ALT)
5. Side button 2 (Defaulted to CTRL)
6. Side button 3 (Defaulted to SHIFT)
7. Rapid fire button (Defaulted to three rapid clicks of the left mouse button)
8. DPI+ button (Defaulted to speed up the cursor)
9. DPI- button (Defaulted to slow down the cursor)
10. E- button(Defaulted to link to homepage)
11. Power switch button (Power ON/OFF/Economy)

Software Instruction

After installing the software on your computer, you can adjust the following settings

1. Adjust the mouse DPI in 6 level as 500-1000-2000-3000-4000-7200
2. Adjust the mouse polling rate in 3 level as 125Hz-250Hz-500Hz
3. Macro management function: you can assign the macro recording to single key
4. Combo key function: you can set click times and delay times of key
5. Customize the function of the mouse button of the mouse buttons(9 buttons)
6. Memorize 5 profile and switch among them using bottom toggle key

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly to the corresponding computer USB port, or try another USB port.
2. If the mouse cursor is moving slowly, jumping, or lagging, try using another surface. Surfaces that are dark, dirty, not flat, or shiny may affect the performance of the mouse. Use of a mouse pad is strongly recommended.



Piece parts	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Plastic parts	○	○	○	○	○	○
Metal parts	○	○	○	○	○	○
Circuit components	○	○	○	○	○	○
Cable	○	○	○	○	○	○

Note:
○ = indicates the percentage of toxic or harmful substances in the parts.



Our products do not contain toxic or harmful substances. They are environmentally friendly and can be recycled.

Name of commodity	Day Month Year		
	Warranty is valid within 18 months from the purchase date.		
Customer	Name:		
	Tel:	Zip code:	
	Address:		
Retailer	Address:		
	Tel:	Zip code:	