

## US UK

### Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

1

## KEYBOARD

### How to connect the keyboard with a computer

#### Wired Connection

1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to OFF.
2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer.
3. The computer will recognize and configure the keyboard automatically.
4. The keyboard will be ready for use when the configuration is finished.
5. Once the keyboard is powered up, charging begins. The LED marked with M light in red. It will turn to green when keyboard is fully recharged.

#### 2.4G Wireless Connection

1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to 2.4G.
2. Press [FN]+[2.4G] for about 3 seconds, the LED marked with M flashes in yellow, plug the USB receiver into any available USB port on your computer within 20 seconds.
3. The computer will recognize and configure the keyboard automatically.

#### Bluetooth Connection

1. Slide the 2.4G/OFF/BT switch on bottom of keyboard to BT.
2. Press [FN]+[BT1] (or [BT2]/[BT3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others)
3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0KB or BT5.0 KB" device. Select it and it will connect automatically.

#### Function Introduction

1. With standard USB and 2.4G/BT connections, the keyboard can be used on computers without any software or driver installation.

2

2. There are 18 backlight patterns: FN+"Right\_Alt" to switch in 18 light patterns.
3. Commands of key combinations with [FN] key

[FN]+[ESC]: ` ~  
[FN+1] = F1  
[FN+2] = F2  
[FN+3] = F3  
[FN+4] = F4  
[FN+5] = F5  
[FN+6] = F6  
[FN+7] = F7  
[FN+8] = F8  
[FN+9] = F9  
[FN+0] = F10  
[FN+\*,\_] = F11  
[FN+\*=+] = F12  
[FN] + [Win]: Disable or enable the [Win] key.  
[FN] + [Q]: Select Bluetooth device one (for Bluetooth connection).  
[FN] + [W]: Select Bluetooth device two (for Bluetooth connection).  
[FN] + [E]: Select Bluetooth device three (for Bluetooth connection).  
[FN] + [R]: Change to 2.4G wireless connection.  
FN+P = PRNTRSC  
FN+{ (= SCRLK  
FN+} = PAUSE  
FN+L = INSERT  
FN+; = HOME  
FN+` = END  
FN+,< = DELETE  
FN+,> = PGUP  
FN+/? = PGDN

3

FN+L\_CTRL = APP  
FN + TAB: Set the keyboard to default setting.  
FN+SPACE: Change backlight color.  
FN+ = \*  
FN+ - = /  
FN+Z = Volume-  
FN+X = Volume+  
FN+C = Mute  
FN+V = Stop  
FN+B = Previous Track  
FN+N = Pause  
FN+M = Next Track  
FN+↑ / ↓ : Decrease/increase the backlight brightness level.  
FN+ ← / → : switch light rotating speed.  
FN+Backspace: Turn ON/OFF the backlight

#### Keyboard sleep mode and power save function

In 2.4Ghz and Bluetooth connecting, to save power, there are two conditions that keyboard get into sleep mode, all LEDs and backlight turn OFF, please click any key to wake up the keyboard.

1. power save mode at the first 3 minutes out of working, all backlight turns OFF, keyboard is working, 2.4G connecting is activity.
2. Sleep mode at the 30 minutes out of working, backlight turns OFF, keyboard is OFF, 2.4G is not connecting.

#### Battery status indication

Press FN+"shift\_R", all backlight turn OFF, the Number keys from 【1】 - 【0】 are indicator of power status as from 0%-100%, when 【1!】 - 【3#】 are ON red means keyboard is low power, need to be charge ASAP.

4

#### How to charge keyboard

Find the USB A to USB type C cable in the packaging, plug the keyboard and connect it with computer for charging, the LED indicator of keyboard will be turn to red.

**Remark:** The LED indicator will be turn to red when keyboard is out of battery.

#### Indicators on keyboard up of left

"A" is for Captals lock indication  
"M" is for connection mode indication

#### FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

5

## MOUSE

### Installation

Plug Nano receiver to USB port on your computer.  
Make sure the switch on bottom of mouse was set as ON mode.  
Press any key to get mouse ready to work.

### Charging your mouse

The battery indicator LED located under the scroll wheel key, it is flash slowly in RED while gaming mouse is out of power, please connect the mouse and computer with the type C-USB cable, the charging time is around 2 hours, it is workable while charging.

### Wake up your wireless mouse

To save power, Mouse was program with a sleeping mouse when it is out of work for 1 minutes, Please press any key to wake up the mouse.

### Wired connecting

Find the type C-USB cable in the packaging, with the mode button(Located at mouse bottom), plug the mouse to PC by cable for wired connection, it is charging at the same time.

### Pairing in 2.4G mode

Find USB Nano receiver in packaging, switch the mode button(Located at mouse bottom) to 2.4G, plug the receiver to PC USB port, press any key of mouse for activity.

### Reconnection


Both of mouse and Nano receiver has a built-in code. It can be setting one mouse to one receiver, or few of mouse to one receiver. Mouse and receiver need to reconnect under the condition of High temperature, high magnetic, strong vibrate.  
Plug off nano receiver from USB port, and plug it on  
Keep the mouse in 50CM with receiver, re-store the battery, put the switch at " OFF".

6

press and hold right key and scroll key and left key for three seconds.  
Connection completely.


### Pairing in bluetooth mode

Switch the mode button to BT (located at bottom of mouse), press and hold mouse pair button (Right next to mode button)for 3 seconds, scan the device on PC/tablet/notebook/MAC, find the mouse device name BT 5.1 Mouse.



### Button Instructions

1. Left mouse button.
2. Right mouse button.
3. Scroll wheel (click as middle mouse button).
4. Side key, defaulted function: FORWARD key on the keyboard.
5. Side key, defaulted function: BACKWARD key on the keyboard.
6. DPI+ button (defaulted to speed up the cursor).
7. DPI- button (defaulted to slow down the cursor).
8. BT pair button.



7

### DPI adjustment Instructions

User mode indicator light: Located below the Scroll Wheel key.  
Red ----- Gear 1 (800 DPI)  
Blue ----- Gear 2 (1200 DPI)  
Green ---- Gear 3 (1600 DPI)  
Purple --- Gear 4 (2400 DPI)  
Yellow --- Gear 5 (7200 DPI)

### Software Instructions

User can adjust the following settings through the software after downloading and installing it.

1. Adjust the DPI of the mouse at the user's discretion. (range: 800-7200 DPI).
2. Adjust the polling rate of the mouse at the user's discretion. (range: 125HZ-250HZ-500HZ-1000HZ). stroke function: Set the number of clicks and delay time.
5. Customized 7 mouse buttons.
6. Customized RGB backlight in patterns/brightness/speed.

### FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



8

### BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.  
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.  
DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.  
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.  
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.  
DO NOT impact, bend, alter, disassemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

**CAUTION:**  
Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

**This device contains licence-exempt transmitter(s) / receiver(s)** that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

**Cet appareil contient des émetteurs / récepteurs** exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

9

### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help  
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

10

封底

封面

|    |                  |   |      |    |     |    |  |
|----|------------------|---|------|----|-----|----|--|
| 型号 | S136 (8672+2910) | 备注：尺寸：100x100mm (折页)<br>材质：80g书写纸<br>印刷：单黑色双面印刷 | 文件编号 | 版本 | A.1 |    |  |
| 名称 | 说明书              |   |      |    |     |    |  |
| 日期 | 2023-11-27(修改)   |   |      |    |     |    |  |
| 页码 | 1 OF 1           | 绘图  | 雷国建  | 审核 | 香敏琪 | 核准 |  |